

For your convenience we have included this installation guide to help you see how each panel may be used as you sign your store.



## 4 SLOT CONFIGURATIONS

# PhotoReal™

©WP Sign Systems 2006

7.5" wide x 2.5" name/picture panel



2.5" high  
combo digit panels

overlap with single  
digits for prices not  
ending in 9



## 2 SLOT CONFIGURATIONS



Below: Shown with space-saving 1 slot (1.25" high) numbers and origin panels



**CLIP SIGNS:** Adapta-Strip™ system means no permanent attachments on the back of clip signs. Slide in Attachments for basket clip, shelf clip, magnetic, and uni-joint clip.

**NOTE:** Make sure the first 4 foot channel section is mounted square and level with your case. This will allow each subsequent section to be placed end to end and remain square and level. The surface of the area where you are mounting channel must be clean and dry. If you are mounting the channel where fresh paint has been applied, make sure the paint is completely dry. If the surface of the case where the channel is being applied is uneven, apply double-sided tape to the case first, then apply the channel. This will make sure there is sufficient surface contact to hold the channel. When mounting the channel, apply adequate pressure over the tape areas to create a good bond between channel and case. Channel has been notched every 24 inches to allow easy insertion and removal of 1 slot product panels. Thank you for using WP Sign Systems.